for sensors with sin/cos output 1 V_{pp}

Technical information Version 2021-06

General information

- Test of any sensors with sin/cos output 1 V_{pp}, for example MiniCODER
- Transfer of data via Ethernet or WLAN to mobile terminal devices (tablet, PC, etc.)
- Visualization of data in web browser, independent of operating system
- Use to check signals for compliance with adjustable tolerance presets
 - sin/cos signals (amplitude, offset, phase offset)
 - Reference signal (amplitude, offset, position and width)
 - Target wheel (damage, concentricity, toothing quality)
- Setting and saving different tolerance presets
- Use for setting parameters of the MiniCODER with optional extras P
 - Automatic adjustment of sin/cos signals
 - Configuring/reading the operating hours meter
 - Storing the 7 configurable rotational speed ranges of the operating hours meter in a record
 Filing multiple records possible in GEL 211CS0

Properties

- Compact and portable device
- Visualization on web-enabled terminal devices

Advantages

- Facilitates assembly:
 Signal analysis is extremely simple thanks to speedy evaluation of the measuring signals, interactive signal correction and graphic evaluation.
- Optimizes maintenance and service work:
 Diagnostics and setting the parameters of the MiniCODER with optional extras P is done in assembled state, for example without opening the spindle, which is particularly convenient and efficient.
- Increases reliability:
 Documentation of the spindle histogram and the measured values from the analyses is done automatically by generating a report that can be printed and saved.

Field of application

- Servicing and commissioning of machine tools
- Servicing and commissioning of HSC spindles
- Servicing and commissioning of motors





Internet: www.lenord.com E-Mail: info@lenord.de Phone: +49 208 9963-0 Lenord, Bauer & Co. GmbH Dohlenstraße 32 46145 Oberhausen, Germany




Description


Design

The testing and programming unit can be integrated into an existing measuring circuit/test station or operated separately.


Device overview



Rear side GEL 211CS0_W2M (WLAN)



Rear side GEL 211CS0_E2M (Ethernet)



- 1 Sensor connection
- 2 Control connection
 - Supply voltage device
 - Supply voltage sensor
 - Connection control system for inline measurement
- 3 WLAN aerial
- 4 Indicators (Power/Comm/Signal/Status)
- 5 Micro USB connection (type B):
 - Integration in an existing radio network
 - Firmware update
 - Changes to settings (for example, WLAN password)
 - Data transmission
- 6 Ethernet connection (RJ45 female socket)
 - Integration in an existing cable network


For the duration of the analysis and setting of parameters the sensor⁽¹⁾ is connected to the sensor connection. Power supply to the device and the connected sensor is via the control connection.

Using the GEL 211CS0, sensor signals are checked for compliance with the tolerance presets. Various tolerance presets can be stored and invoked for this purpose.

⁽¹⁾ only MiniCODER with optional extras **P**

Description

Example of use



Functional description

Function	Description	
Signal analysis: SIN/COS	 Amplitude (peak-to-peak) of sin/cos signals Amplitude difference (synchronization error) Offset of sin/cos signals Phase deviation between sin and cos signals 	
Signal analysis: REF	 Amplitude of reference signal Idle level of reference signal Position and width 	
Target wheel analysis (1)	 Target wheel concentricity and roundness via sin/cos signal fluctuation Toothing quality and signal quality via the standard deviation of the BQ value Identification of target wheel damage via the difference between BQ_{min} and BQ_{max}. Damage to the tooth structure is indicated by significant jumps in the analysis curve. 	
Automatic sensor alignment	 Optimization of amplitude synchronism Step-by-step decrease/increase of the amplitudes of the sin/cos signals Minimizing the offset of sin/cos signals Wizard for optimization of installation times with automatic analysis reporting 	
Analysis reports	 Creating a report with the measured values from the SIN/COS and REF signal analysis and target wheel analysis 	
Spindle histogram	 Setting 7 rotational speed ranges Recalling and saving operating hours Recalling and saving number of run-ups Creating an operating hours report 	
Information about sensor	 Reading out spindle number (spindle assignment) Reading out type code and serial number for sensor identification Total operating time of sensor Temperature peaks in sensor: highest and lowest measured temperature 	
Information about GEL 211CS0	Firmware versionSerial numberWLAN SSID	

 $[\]begin{tabular}{ll} \begin{tabular}{ll} \beg$

Description

Functionality

The functionality of the testing and programming unit depends on the sensor.

Functionality for MiniCODER with reference signal

Function	MiniCODER			MiniCODER with optional extras P
	GEL 2444K_R GEL 2444L_R	GEL 2444K_1 GEL 2444L_1	GEL 2444D_	GEL 2444K_P GEL 2444L_P GEL 2449K_P
Signal analysis: SIN/COS	②	②		②
Signal analysis: REF	②	②		②
Target wheel analysis (1)		②		②
Automatic sensor alignment				②
Analysis reports	②	②		②
Spindle histogram			②	②
Information about sensor			②	②
Information about GEL 211CS0	depends on the sensor			

Functionality for MiniCODER without reference signal⁽²⁾

Function	MiniCODER		MiniCODER with optional extras P
	GEL 2444K-R GEL 2444L-R	GEL 2444K-1 GEL 2444L-1	GEL 2444K-P GEL 2444L-P
Signal analysis: SIN/COS	②	②	②
Signal analysis: REF			
Target wheel analysis (1)		②	②
Automatic sensor alignment	•		②
Analysis reports	②	②	②
Spindle histogram			
Information about sensor		•	②
Information about GEL 211CS0	depends on the sensor	ı	-1

Explanation about sensor type (optional extras as per type code)

- R with internal amplitude control
- 1 without internal control
- P parameterizable
- Reference mark M, N, Z
- without reference mark

Function usable

Function not usable

⁽¹⁾ The target wheel is analyzed using a mathematically determined evaluation quotient (BQ value).


⁽²⁾ Wizard is not available

User interface

The testing and programming unit communicates via Ethernet or WLAN using a web-enabled client (PC, tablet, etc.) and is controlled via the web interface. It requires a current browser or a current operating system for mobile terminal devices

The interface can be accessed via the device IP address.

The web interface was developed with mobile terminal devices in mind, so that it can be used even on smaller displays. For optimal operation, a display with a screen diagonal of 7 inches or higher is recommended.



Web interface start screen



Display of the sin/cos signals for signal analysis Indication of the tooth-to-tooth values and display of mean values over one revolution



Definition of rotational speed ranges for the MiniCODER with optional extras **P**



Operating time in different rotational speed ranges Visualization of configurable operating hours meter in the MiniCODER with optional extras **P**


Technical data

Electrical data		
Supply voltage U _B	+5 V DC	
Current consumption via USB port	≤ 500 mA	
Connections	Sensor: M23 female sockets, 17 pin; Control: M23 male pins, 17 pin USB (micro USB, type B) Ethernet (RJ45 female socket, only GEL 211CE2)	
Data transmission Ethernet	Ethernet Report files: Ethernet or USB	
Data transmission WLAN	WLAN Report files: WLAN or USB	
Mechanical data		
Housing material	Aluminum anodized, black	
Weight	approx. 0.5 kg	
Dimensions (without connector/aerial)	130 mm × 123 mm × 45 mm	
Ambient data		
Operating temperature range	0 °C to +70 °C	
Storage temperature range	-20 °C to 85 °C	
Degree of protection	IP 20	
Maximum relative air humidity	80%	
Condensation	not permitted	

WLAN module approvals	
IC ID	21098-ESPWROOM32
Transmission power	< 16 dBm
Frequency range	2412 to 2462 MHz
Application area	European Union Member States and Norway, Switzerland, Iceland, Liechtenstein


Dimensional drawings

Dimensional drawing GEL 211CS0_W2M (WLAN)



Dimensional drawings

Dimensional drawing GEL 211CS0_E2M (Ethernet)



Connection

	Pin	Function (evaluated by GEL 211C	S0)
	1	Signal track 1	U ₁₊
1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	2	Inverse signal track 1	U ₁₋
12 12 16 9 P	3	Signal reference track N	U _{N+}
13 13 15 15 15 15 15 15 15 15 15 15 15 15 15	7	GND	0 V
● ⁵ 6 ⁷ ● 7 0 7 0 0 7 0 0 7 0 0 1 0 0 0 0 0 0 0 0 0 0	10	+5 V supply voltage	U _B
	11	Signal track 2	U ₂₊
Female sockets	12	Inverse signal track 2	U ₂₋
sensor	13	Inverse signal reference track N	U _{N-}
(10 10 10 10 10 10 10 10 10 10 10 10 10 1	The pin assignment corresponds to the MiniCODER standard. Input and output connections with the same number (1–9, 11–15, 17) are looped through; sense input 16 is connected to input 10 (supply voltage). Connections not listed are not used by GEL 211CS0.		
Male sockets			
control			



If the device is operated with a higher-level control system connected, two operating modes must be differentiated:

- Measurement/Analysis: No restriction of operation
- Configuration/Adjustment: Restriction of operation, as the MiniCODER with optional extras **P** is set temporarily to programming mode in which "Safety integrated" is no longer guaranteed.

Testing and programming units

Product	Testing and Programming Unit	Note
GEL 2444D	GEL 211CS 0 4E2M (Ethernet)	Only available as configuration kit
GEL 2444K	GEL 211CS 0 4W2M (WLAN)	PK211C-244XK-E (Ethernet), comprising:
GEL 2444L		 Testing and programming unit GEL 211CS04E2M
GEL 2449K	К	Sensor connection cable GG211Power supply unit 5 V, ZB211CB
		Operating instructions D-71B-211CS0Case, XW1303
		PK211C-244XK-W (WLAN), comprising: Testing and programming unit GEL 211CS04W2M Sensor connection cable GG211 Power supply unit 5 V, ZB211CB Operating instructions D-71B-211CS0
		Case, XW1303
GEL 2311B	GEL 211CST4E2M (Ethernet) GEL 211CST4W2M (WLAN)	Only available as configuration kit
GEL 2444M	GLE 2110014WZW (WLAW)	PK211C-244XM-E (Ethernet), comprising: Testing and programming unit GEL 211CST4E2M Universal adapter box, ZB2449M4
GEL 2449M		
		Power supply unit 5 V, ZB211CBOperating instructions, D-71B-211C
		= Case, XW1303
		PK211C-244XM-W (WLAN), comprising: Testing and programming unit GEL 211CST4W2M Universal adapter box, ZB2449M4 Power supply unit 5 V, ZB211CB Operating instructions, D-71B-211C Case, XW1303
GEL 2800	GEL 211CS S 4E2N (Ethernet) GEL 211CS S 4W2N (WLAN)	Only available as configuration kit
	OLE ZITOGO WZIN (WZINI)	PK211C-2800-E (Ethernet), comprising: Testing and programming unit GEL 211CSS4E2N Power supply unit 24 V, ZB211CA Adapter box, 2150A211 Operating instructions, D-71B-211C Case, XW1303
		PK211C-2800-W (WLAN), comprising: Testing and programming unit GEL 211CSS4W2N Power supply unit 24 V, ZB211CA Adapter box, 2150A211 Operating instructions, D-71B-211C Case, XW1303
GEL 247(x)	GEL 211CSR4E2D (Ethernet) GEL 211CSR4W2D (WLAN)	The encoders may only be connected via the GG211RY001 interface.
GEL 293	GEL 211CSR4E2D (Ethernet) GEL 211CSR4W2D (WLAN)	The encoders may only be connected via the GG211RY001 interface.

Notes:



Lenord, Bauer & Co. GmbH Dohlenstraße 32 46145 Oberhausen, Germany

Phone: +49 208 9963–0 Fax: +49 208 676292 Internet: www.lenord.com E-Mail: info@lenord.de

Right to technical changes and errors reserved.